

### Introduction

LigaTrap Mouse IgM Purification Resin is engineered to purify high quality Mouse IgM antibodies from polyclonal and monoclonal sources. LigaTrap Mouse IgM Purification Resin is <u>capable of binding  $\geq$  10 mg</u> <u>Mouse IgM /mL resin</u>. The LigaTrap Mouse IgM Purification Kit provides all the necessary reagents for fast, convenient micro-scale purification of Mouse IgM in just 12 easy steps. Each kit contains 10 microspin columns prefilled with 0.1 mL of LigaTrap Mouse IgM Purification Resin, buffers, and collection tubes. Each microspin column may be used, regenerated, and reused up to 10 times with minimal loss in binding capacity. Kappa and Lambda IgM may be purified using this product. **Serum applications are not recommended with all LigaTrap IgM Purification products, due to potential cross reactivity with other immunoglobulins.** 

#### **Kit Contents**

Part #	Item				
LT-145-MSC	<b>Microspin Columns-</b> centrifuge columns supplied with caps and plug. Each microspin column contains 0.1 mL LigaTrap Mouse IgM Purification Resin in LigaTrap Storage Buffer.				
BU-131-FP	LigaTrap Sample Diluent 2.0	15 mL			
BU-132-FP	LigaTrap Equilibration/Wash Buffer 2.0	250 mL			
BU-133-FP	LigaTrap IgM Elution Buffer	125 mL			
BU-124-FP	LigaTrap Regeneration Buffer	50 mL			
BU-125-FP	LigaTrap Neutralization Buffer	15 mL			
BU-126-FP	LigaTrap Storage Buffer	50 mL			
PL-057	2.0 mL Collection Tubes	80			

#### **Additional Materials Required**

- Microcentrifuge set between 1000-3000 x g
- Vortex/Mixer
- Centrifuge tubes or container for sample preparations

## **Antibody Purification Procedure**

> Note: Equilibrate all buffers to room temperature prior to use.

### Sample Preparation

- 1. In a separate tube, add 320µL of sample matrix (i.e. hybridoma supernatant or cell culture fluid) containing Mouse IgM.
- 2. Add 80µL of LigaTrap Sample Diluent 2.0 (BU-131-FP) to the sample. Mix briefly by vortexing.

### Purification

- 3. Snap off the bottom plug on the microspin column. <u>Save this plug, as it will be needed to stopper the</u> <u>column.</u>
- 4. Insert the microspin column into a supplied 2.0 mL collection tube. Equilibrate resin by adding 400µL of LigaTrap Equilibration/Wash Buffer 2.0 (BU-132-FP) to the unplugged microspin column. Centrifuge between 1000-3000 x g for 1 minute. Discard the buffer in collection tube. Repeat for two additional 400µL equilibrations. Insert the bottom plug onto the microspin column.
- Transfer 400µL of the prepared sample (from Step # 2) to the equilibrated column. Place screw cap on snugly. Continue to mix/shake the sample and resin continuously for <u>5 minutes</u>. Remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Centrifuge between 1000-3000 x g for 1 minute. Retain flow through.
- Insert bottom plug onto the microspin column and add 400μL of the LigaTrap Equilibration/Wash Buffer 2.0 (BU-132-FP). Mix/shake resin continuously for 5 minutes. Remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Centrifuge between 1000-3000 x g for 1 minute. Retain wash flow through. Repeat process for a second 400μL wash.
- Insert the bottom plug onto the microspin column and add 400µL of LigaTrap IgM Elution Buffer (BU-133-FP). Mix/shake resin continuously for 5 minutes. Remove bottom plug and insert the microspin column into a new 2.0 mL collection tube labeled <u>Eluate 1</u>. Centrifuge between 1000-3000 x g for 1 minute. Repeat process for a second 400µL elution and use a new 2.0 mL collection tube labeled <u>Eluate 2</u>. <u>Note:</u> The eluates contain the purified antibodies. *Do not discard!*
- Add 50µL (12.5% v/v of elution samples) of LigaTrap Neutralization Buffer (BU-125-FP) to each of the eluates obtained in Step # 7. Vortex briefly. The antibody will be near neutral pH and is ready for downstream applications.

**Note:** There are no preservatives in the antibody. Use the antibody within one week or aliquot and store at -20° C or colder. Avoid multiple freeze thaws.

- Insert the bottom plug onto the microspin column and Add 400µL of LigaTrap Regeneration Buffer (BU-124-FP). Mix/shake resin continuously for 5 minutes. Remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Centrifuge between 1000-3000 x g for 1 minute. Retain regeneration flow through.
- 10. Add 50µL of **LigaTrap Neutralization Buffer (BU-125-FP)** to the regeneration flow through obtained in Step # 9. Vortex briefly.

- 11. If the column will not be reused, it may be discarded. If the microspin column is to be reused, re-equilibrate the resin by repeating the process described in Step # 4.
- 12. To store resin, remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Add 400μL of **LigaTrap Storage Buffer (BU-126-FP)**. Centrifuge between 1000-3000 x g for 1 minute. Repeat for two more 400μL washes. Once complete, insert the bottom plug onto the microspin column and add 400μL of fresh **LigaTrap Storage Buffer (BU-126-FP)**. Store plugged microspin column upright at 2-8° C.

<u>ga p</u>		Part Number			
Target Species	Antibody	Loose Resin	Microspin Columns	Prepacked Columns	Purification Kits
Human	lgG	LT-095	LT-095-MSC	LT-095-1x1mL	LT-095KIT
				LT-095-3x1mL	LT-095-1mL KIT
				LT-095-1x5mL	LT-095-5mL KIT
	lgM	LT-143	LT-143-MSC	LT-143-1x1mL	LT-143KIT
				LT-143-3x1mL	LT-143-1mL KIT
				LT-143-1x5mL	LT-143-5mL KIT
	IgA	LT-146	LT-146-MSC	LT-146-1x1mL	LT-146KIT
				LT-146-3x1mL	LT-146-1mL KIT
				LT-146-1x5mL	LT-146-5mL KIT
Maria	lgG	LT-137	LT-137-MSC	LT-137-1x1mL	LT-137KIT
				LT-137-3x1mL	LT-137-1mL KIT
				LT-137-1x5mL	LT-137-5mL KIT
Mouse	lgM	LT-145	LT-145-MSC	LT-145-1x1mL	LT-145KIT
				LT-145-3x1mL	LT-145-1mL KIT
				LT-145-1x5mL	LT-145-5mL KIT
Rat	lgG	LT-138	LT-138-MSC	LT-138-1x1mL	LT-138KIT
				LT-138-3x1mL	LT-138-1mL KIT
				LT-138-1x5mL	LT-138-5mL KIT
	lgM	LT-147	LT-147-MSC	LT-147-1x1mL	LT-147KIT
				LT-147-3x1mL	LT-147-1mL KIT
				LT-147-1x5mL	LT-147-5mL KIT
Llama	lgG	LT-144	LT-144-MSC	LT-144-1x1mL	LT-144KIT
				LT-144-3x1mL	LT-144-1mL KIT
				LT-144-1x5mL	LT-144-5mL KIT
Goat	lgG	LT-136	LT-136-MSC	LT-136-1x1mL	LT-136KIT
				LT-136-3x1mL	LT-136-1mL KIT
				LT-136-1x5mL	LT-136-5mL KIT
Rabbit	lgG	LT-139	LT-139-MSC	LT-139-1x1mL	LT-139KIT
				LT-139-3x1mL	LT-139-1mL KIT
				LT-139-1x5mL	LT-139-5mL KIT
Chicken	lgY	LT-142	LT-142-MSC	LT-142-1x1mL	LT-142KIT
				LT-142-3x1mL	LT-142-1mL KIT
				LT-142-1x5mL	LT-142-5mL KIT

# Other LigaTrap Products:

For further product information, please visit our website at <u>www.LigaTrap.com</u>. For technical support and questions, email us at <u>info@ligatrap.com</u>