
LigaTrap® Base Resin Purification Kit

Product Instructions

Introduction

LigaTrap Purification Resin is engineered to purify high quality antibodies from polyclonal and monoclonal sources. LigaTrap Purification Resin is recommended for purifying IgG in range of species as well as for Human IgA and Chicken IgY applications. The LigaTrap Base Resin Purification Kit provides all the necessary reagents for fast, convenient micro-scale purification of antibodies in just 12 easy steps. Each kit contains 10 microspin columns prefilled with 0.1 mL of LigaTrap Purification Resin, buffers, and collection tubes. Each microspin column may be used, regenerated, and reused up to 10 times with minimal loss in binding capacity. Kappa and Lambda IgG, IgA, and IgY may be purified using this product.

Kit Contents

Part #	Item	Quantity
LT-150-MSC	Microspin Columns- centrifuge columns supplied with caps and plug. Each microspin column contains 0.1 mL LigaTrap Purification Resin in LigaTrap Storage Buffer.	10
BU-131-FP	LigaTrap Sample Diluent 2.0	15 mL
BU-132-FP	LigaTrap Equilibration/Wash Buffer 2.0	250 mL
BU-123-FP	LigaTrap Elution Buffer	125 mL
BU-124-FP	LigaTrap Regeneration Buffer	50 mL
BU-125-FP	LigaTrap Neutralization Buffer	15 mL
BU-126-FP	LigaTrap Storage Buffer	50 mL
PL-057	2.0 mL Collection Tubes	80

Additional Materials Required

- Microcentrifuge set between 1000-3000 x g
- Vortex/Mixer
- Centrifuge tubes or container for sample preparations

Antibody Purification Procedure

➤ **Note:** Equilibrate all buffers to room temperature prior to use.

Sample Preparation

1. In a separate tube, add 320µL of sample matrix (i.e. hybridoma supernatant or cell culture fluid) containing the target antibody.
2. Add 80µL of **LigaTrap Sample Diluent 2.0 (BU-131-FP)** to the sample. Mix briefly by vortexing.

Purification

3. Snap off the bottom plug on the microspin column. **Save this plug, as it will be needed to stopper the column.**
4. Insert the microspin column into a supplied 2.0 mL collection tube. Equilibrate resin by adding 400µL of **LigaTrap Equilibration/Wash Buffer 2.0 (BU-132-FP)** to the unplugged microspin column. Centrifuge between 1000-3000 x g for 1 minute. Discard the buffer in collection tube. Repeat for two additional 400µL equilibrations. Insert the bottom plug onto the microspin column.
5. Transfer 400µL of the prepared sample (from Step # 2) to the equilibrated column. Place screw cap on snugly. Continue to mix/shake the sample and resin continuously for **5 minutes**. Remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Centrifuge between 1000-3000 x g for 1 minute. Retain flow through.
6. Insert bottom plug onto the microspin column and add 400µL of the **LigaTrap Equilibration/Wash Buffer 2.0 (BU-132-FP)**. Mix/shake resin continuously for 5 minutes. Remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Centrifuge between 1000-3000 x g for 1 minute. Retain wash flow through. Repeat process for a second 400µL wash.
7. Insert the bottom plug onto the microspin column and add 400µL of **LigaTrap Elution Buffer (BU-123-FP)**. Mix/shake resin continuously for 5 minutes. Remove bottom plug and insert the microspin column into a new 2.0 mL collection tube labeled **Eluate 1**. Centrifuge between 1000-3000 x g for 1 minute. Repeat process for a second 400µL elution and use a new 2.0 mL collection tube labeled **Eluate 2**.
Note: The eluates contain the purified antibodies. ***Do not discard!***
8. Add 70µL (17.5% v/v of elution samples) of **LigaTrap Neutralization Buffer (BU-125-FP)** to each of the eluates obtained in Step # 7. Vortex briefly. The antibody will be near neutral pH and is ready for downstream applications.
Note: There are no preservatives in the antibody. Use the antibody within one week or aliquot and store at -20° C or colder. Avoid multiple freeze thaws.
9. Insert the bottom plug onto the microspin column and Add 400µL of **LigaTrap Regeneration Buffer (BU-124-FP)**. Mix/shake resin continuously for 5 minutes. Remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Centrifuge between 1000-3000 x g for 1 minute. Retain regeneration flow through.
10. Add 50µL of **LigaTrap Neutralization Buffer (BU-125-FP)** to the regeneration flow through obtained in Step # 9. Vortex briefly.

11. If the column will not be reused, it may be discarded. If the microspin column is to be reused, re-equilibrate the resin by repeating the process described in Step # 4.
12. To store resin, remove bottom plug and insert microspin column into a new 2.0 mL collection tube. Add 400µL of **LigaTrap Storage Buffer (BU-126-FP)**. Centrifuge between 1000-3000 x g for 1 minute. Repeat for two more 400µL washes. Once complete, insert the bottom plug onto the microspin column and add 400µL of fresh **LigaTrap Storage Buffer (BU-126-FP)**. Store plugged microspin column upright at 2-8° C.

Other LigaTrap Products:

Product	Antibody	Part Number			
		Loose Resin	Microspin Columns	Prepacked Columns	Purification Kits
LigaTrap Base Resin	IgG, IgA, IgY	LT-150	LT-150-MS	LT-150-1x1mL LT-150-3x1mL LT-150-1x5mL	LT-150KIT LT-150-1mL KIT LT-150-5mL KIT
LigaTrap IgM Resin	IgM	LT-155	LT-155-MS	LT-155-1x1mL LT-155-3x1mL LT-155-1x5mL	LT-155KIT LT-155-1mL KIT LT-155-5mL KIT

For further product information, please visit our website at www.LigaTrap.com. For technical support and questions, email us at info@ligatrap.com